

Cutting Diamond Tools By Laser MicroJet®

New developments in the wet laser machining of
industrial diamond tools

Sébastien KURZEN
Application Engineer
Synova S.A.



Speaker introduction

- Sébastien Kurzen
- Synova S.A. – Switzerland
- Application Engineer
- Diamond tools
- Simultaneous 5-axis machining for diamond tools and CAD/CAM software

Presentation Contents

1. Company
2. Laser MicroJet® technology
3. LCS 50-5
4. State of the art results cutting PCD/WC
5. State of the art results cutting SCD
6. Conclusions


1. Company

- Laser cutting machines (using the Laser-MicroJet principle)
- HQ in Duillier, near Geneva, Switzerland
- Founded in 1997
- 75 employees
- Micro-Machining Centers (MMC's) in the USA, India, Korea, Japan

2. Laser MicroJet[®] (LMJ) technology


2. Laser MicroJet® (LMJ) technology

- Laser beam focused into nozzle aperture



2. Laser MicroJet® (LMJ) technology


- Laser beam focused into nozzle aperture
- Laser light guided within water jet by total internal reflection



2. Laser MicroJet® (LMJ) technology

- Laser beam focused into nozzle aperture
- Laser light guided within water jet by total internal reflection
- Laser pulses evaporate material, water cools and cleans between the pulses
- By scanning, a trench is formed which becomes deeper with each pass

2. Laser MicroJet® (LMJ) technology





https://youtu.be/Q_IRaONosxc?t=54s


2. Laser MicroJet® (LMJ) technology


Advantages are:

- No focus adjustment
- Parallel sided kerf
- Minimal heat affected zone
- High material removal rate
- Debris washed from kerf









3. LCS 50-5

Mainly used to cut:


- Polycrystalline diamond (on WC) & PcBN
- Single crystal diamond (HPHT or CVD)
- Natural diamond
- Ceramics
- Metals

3. LCS 50-5

Mainly used to cut:






- **Polycrystalline diamond (on WC) & PcBN**
- **Single crystal diamond (HPHT or CVD)**
- Natural diamond
- Ceramics
- Metals

3. LCS 50-5



4. State of the art results cutting PCD/WC


- All kinds of tools / geometries can be cut



4. State of the art results cutting PCD/WC


PCD/WC cutting

LMJ vs EDM








Uniform cut surface profile


LMJ vs dry laser



Parallel cutting




4. State of the art results cutting PCD/WC




4. State of the art results cutting PCD/WC

Edge waviness ≤ 1 micron




0.5 μm PCD grains

4. State of the art results cutting PCD/WC



5000x

4. State of the art results cutting PCD/WC




4. State of the art results cutting PCD/WC


	Programmed	Measured
Primary clearance angle	8.0°	8.2°
Primary clearance depth	500 μm	510 μm
Secondary clearance angle	20.0°	20.1°
Cutting edge radius	-	< 2 μm
Roughness below cutting edge	-	Ra = 0.21 μm , Rz = 1.5 μm
Effective cutting speed	-	1.5 mm/min

5. State of the art results cutting SCD

- All kinds of tools / geometries can be cut




5. State of the art results cutting SCD




5. State of the art results cutting SCD

Edge waviness ≤ 0.5 micron




5. State of the art results cutting SCD

Edge waviness ≤ 0.5 micron



5. State of the art results cutting SCD

Edge waviness ≤ 0.5 micron



500x

20 um

5. State of the art results cutting SCD


Edge waviness ≤ 0.5 micron



1000x


5. State of the art results cutting SCD

Cutting trenches are visible but no impact on roughness



20x

5. State of the art results cutting SCD




	Angle [°]	Distance [nm]	P1.x [μm]	P1.y [cm]	P2.x [μm]	P2.y [cm]	P3.x [μm]	P3.y [cm]	P4.x [μm]	P4.y [cm]
Heightstep 1	136.6091	980.7433	99.1734	1.7528	168.1201	1.7462	167.2750	1.7462	99.1734	1.7526


Wave height < 1 μm




5. State of the art results cutting SCD



5. State of the art results cutting SCD



5. State of the art results cutting SCD



5. State of the art results cutting SCD

	Programmed	Measured
Clearance angle	10.0°	9.9°
Cutting edge radius	-	2.7 μm
Roughness below cutting edge	-	Ra = 0.25 μm , Rz = 1.4 μm
Effective cutting speed	-	2.6 mm/min

6. Conclusion 1/3 – The results

- Sub-micron surface finish can be reached for both PCD and SCD materials
- Such result is possible even at cutting speeds up to 1.5 mm/min for PCD and 2.6 mm/min for SCD
- HAZ depth is 5 μm , according to Sumitomo
- Edge micro-cracking compared to dry lasers reduced or eliminated

6. Conclusion 2/3 – the machine

- Very compact machine (800 x 1200 x 1650 mm)
- Full 5-axis capability
- Very easy to operate (HMI)
- Intuitive CAM software for diamond tools including auto-probe-correction and batch processing
- Automatic probe-based correction by CAD/CAM for more complex tools (“SynovaCut”)

6. Conclusion 3/3 – the machine

- Cutting strategies can be implemented in a production mode
- Unlimited choice of materials and thicknesses
- Low cost of ownership
- Faster cutting/shaping means fewer machines required → reduced capital investment

Thank you for your attention!



SYNOVA

Sébastien Kurzen
Application Engineer
Synova S.A.
skurzen@synova.ch

6. Appendix – SynovaCut demo

